

Identificación Conectores RF.

| | | | |
|--|--|--|---|
|  <p>BNC Plug (Male)</p> |  <p>RP-BNC Plug (Male)</p> |  <p>RP-BNC Jack (Female)</p> | |
|  <p>N-Male</p> |  <p>N Jack (Female)</p> |  <p>N Jack (Female) Bulkhead</p> | |
|  <p>SMA Plug (Male)</p> |  <p>SMA Jack (Female)</p> |  <p>RP-SMA Plug (Male)</p> |  <p>RP-SMA Jack (Female)</p> |
|  <p>RP-SMA Jack (Female) Bulkhead</p> | | | |
|  <p>TNC Plug (Male)</p> |  <p>TNC Jack (Female)</p> |  <p>RP-TNC Plug (Male)</p> |  <p>RP-TNC Jack (Female)</p> |

| | | | |
|---|---|--|---|
|  |  |  | |
| FME Plug (Male) | FME Jack (Female) | SMB Plug | |
|  |  |  |  |
| MC Card Plug (Male) | MCX Plug (Male) | MMCX | RP-MMCX |
|  |  |  | |
| UHF Plug (Male) | Mini-UHF Plug (Male) | Mini-UHF Jack (Female) | |
|  | | | |
| U.FL | | | |